

HDSF Destratification Fan

Installation and Maintenance Instructions.

THESE INSTRUCTIONS MUST BE READ FULLY BEFORE COMMENCING INSTALLATION.

Owner / installer: The life of this apparatus and its efficiency will be increased if its use and maintenance is carried out in accordance with these instructions and current statutory requirements. The installation and initial adjustments should be carried out by a qualified and competent technician. Hydor Limited should be consulted before substituting or fitting parts from another manufacturer. It is the responsibility of the installer to verify that the installation is in accordance with the following standards and the owner is given the current User's Manual.

Any modifications to the fan or its installation, even the smallest modification, change or elimination of security components or pieces that influence the efficiency or loss of ventilation, will result in the CE Certification and Hydor's warranty being cancelled.

Model	Speed r/min	Supply V-Ph-Hz	Power Watts	FLC Amps	Start Amps	Airflow m ³ /s	Throw metres	Weight Kg
HDSF500/6/1/230	900	230-1-50	190	1.5	3.4	1.52	15-20	25
HDSF500/6/3/230	900	230-3-50	190	1.4	3.3	1.52	15-20	25
HDSF500/6/3/415	900	415-3-50	190	0.9	2.3	1.52	15-20	25
HDSF630/6/1/230	940	230-1-50	390	2.9	7.6	3.11	25-30	35
HDSF630/6/3/230	940	230-3-50	390	2.7	7.4	3.11	25-30	35
HDSF630/6/3/415	940	415-3-50	390	1.5	3.6	3.11	25-30	35

1. General

- 1.1 It is important these Installation and Maintenance Instructions are fully adhered to.
- 1.2 Full details of the unit supplied are shown on the product nameplate. If in doubt about any detail contact Hydor or its agents for clarification.
- 1.3 All electrical installations must be carried out by suitably qualified and

competent personnel in accordance with all current statutory requirements.

- 1.4 These instructions cover only the Hydor product and do not include the supply or installation of any safety equipment that may be required e.g. proper electrical isolation.
- 1.5 Any declarations made by Hydor about product installation and safety, are dependent on the fan unit being used within installations which themselves meet the requirements of the relevant Standards and Directives of your region.
- 1.6 The fan unit is designed for use in an ambient temperature of up to 50°C and 95% relative humidity. The fan unit is not suitable for corrosive or explosive atmospheres.
- 1.7 The installer should provide easy access to the fan to facilitate future maintenance.
- 1.8 The installer should ensure the fan unit is adequately supported.
- 1.9 This product is not intended for the use of young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the product safely. Young children should be supervised to ensure that they do not play with the appliance.

WARNING The fan unit must be isolated from the power supply during installation and maintenance. The fan must be earthed in accordance with the local regulations.

2. Installation

- 2.1 Upon receipt, the fan unit should be visually inspected to check for any damage. Ensure that the impeller is free to rotate.
- 2.2 If there are any queries concerning the fan unit, Hydor should be contacted prior to installation.
- 2.3 The fan unit should be securely mounted in the required position to suit the application.
- 2.4 Check the details on the motor rating plate to ensure that the correct power supply [voltage, frequency and phase] and starters are available. Particularly if the motors are to be controlled by an inverter speed control. An incorrect power supply will lead to permanent damage to the motor.
- 2.5 Means for electrical disconnection must be incorporated in the installation in accordance with the relevant the wiring and electrical regulations. Ensure that all earth connections are made and secure.
- 2.6 If the fan is being used through a speed control device, either electrically or electronically, refer to the relevant control device instructions. Before commencing installation.

3. Operation

- 3.1 Before power is supplied to the unit, check that the wiring is correct as per the fan connection diagram and control instructions [If fitted].
- 3.2 At initial start-up, check that the impeller rotation and airflow direction is correct.
- 3.3 Check that the motor amperage drawn does not exceed the nameplate rating at full speed.

4. Fan Maintenance

- 4.1 Inspection of the fan unit at least every 6 months is recommended to ensure that the motor and fan blades are clean. Any build-up of dust deposits should be removed using a non-abrasive cleaner.
- 4.2 All fastenings should be checked for tightness. In addition, all rotating items should be checked.
- 4.3 Bearings are of the "sealed for life" variety and will not need a detail inspection.

WARNING Only a suitably qualified and competent person may carry out maintenance after the electrical supply has been isolated. Particular care must be taken when automatic switching controls are used.

Guarantee

Hydor or its agents will, within a period of one year from the date of dispatch from their works, at its option, replace any goods, which are proven to have defects as a result of defective materials or workmanship. The goods must be inspected by a Hydor official and if necessary returned, with a Returns Note Number, carriage paid, for further examination.

Hydor Ltd

Hydor

Unit 8, Parkers Close, Downton Business Centre,
Downton, Salisbury, Wiltshire, SP5 3RB, UK

Tel: +44 (0) 1725 511422

Fax: +44 (0) 1725 512637

Email: info@hydor.co.uk

Web: www.hydor.co.uk

idealair group

Unit 1, Building 1, Sydney Corporate Park,
85 O'Riordan Street, Alexandria NSW 2015

Tel: +61 (02) 8073 3310

Fax: +61 (02) 8073 3320

Email: info@idealairgroup.com.au

AMS

11 Ingrid Road, Montague Gardens,
7442 Cape Town, Western Cape

Tel: +27 (0) 21 552 1077

Fax: +27 (0) 21 552 2797